

RW BLE Host Error Code

Interface Specification

RW-BLE-HOST-ERR-CODE-IS

Version 11.2

2021-03-09



Revision History

Version	Date	Revision Description	Author
1.0	2012-12-13	Added error codes	KY/FBE
2.0	2013-03-10	Update error codes table	FBE
7.00	2014-06-30	BLE 4.1 HL Error Codes	FBE
7.01	2015-01-06	Add new error code for L2CAP LE Credit Based Connection	FBE
8.00	2015-06-29	Update Error codes for BLE 4.2	FBE
8.01	2015-10-26	Add some new error codes for Audio Mode 0	FBE
8.02	2016-04-15	New error code for LE Credit Based Connection	FBE
8.02	2016-12-12	New error code for LE Credit Based Connection	FBE
9.0	2017-03-09	Update for BLE 5	LT
10.0	2018-10-24	Update for BLE 5.1	FBE
11.0	2019-11-27	Update for 5.2	FBE
11.1	2020-01-17	Update versions to 5.2 number	FBE
11.2	2021-03-09	Add new GAP error code	FBE



Table of Contents

Revision History	2
Table of Contents	3
List of Tables	4
1 Abbreviations	5
2 Document Overview	6
3 Error Code List.....	7



List of Tables

Table 1: Host Stack Error Codes 12



1 Abbreviations

Abbreviation	Original Terminology
API	Application Programming Interface
ATT	Attribute
BLE	Bluetooth Low Energy
GAP	Generic Access Profile
GATT	Generic Attribute Profile
SMP	Security Manager Protocol
RW	RivieraWaves



2 Document Overview

This document describes the non-standard error code interface of the RW BLE Host implementation.

These error codes can be triggered by any host task such as GAP, GATT, SMP, ATT or profiles



3 Error Code List

Value	Error	Description
0x0000	GAP_ERR_NO_ERROR	No error
ATT Error Codes		
0x0001	ATT_ERR_INVALID_HANDLE	Handle is invalid
0x0002	ATT_ERR_READ_NOT_PERMITTED	Read permission disabled
0x0003	ATT_ERR_WRITE_NOT_PERMITTED	Write permission disabled
0x0004	ATT_ERR_INVALID_PDU	Incorrect PDU
0x0005	ATT_ERR_INSUFF_AUTHEN	Authentication privilege not enough
0x0006	ATT_ERR_REQUEST_NOT_SUPPORTED	Request not supported or not understood
0x0007	ATT_ERR_INVALID_OFFSET	Incorrect offset value
0x0008	ATT_ERR_INSUFF_AUTHOR	Authorization privilege not enough
0x0009	ATT_ERR_PREPARE_QUEUE_FULL	Capacity queue for reliable write reached
0x000A	ATT_ERR_ATTRIBUTE_NOT_FOUND	Attribute requested not existing
0x000B	ATT_ERR_ATTRIBUTE_NOT_LONG	Attribute requested not long
0x000C	ATT_ERR_INSUFF_ENC_KEY_SIZE	Encryption size not sufficient
0x000D	ATT_ERR_INVALID_ATTRIBUTE_VAL_LEN	Invalid length of the attribute value
0x000E	ATT_ERR_UNLIKELY_ERR	Operation not fit to condition
0x000F	ATT_ERR_INSUFF_ENC	Attribute requires encryption before operation
0x0010	ATT_UNSUPP_GRP_TYPE	Attribute grouping not supported
0x0011	ATT_INSUFF_RESOURCE	Resources not sufficient to complete the request
0x0012	ATT_ERR_DB_OUT_OF_SYNC	The server requests the client to rediscover the database.
0x0013	ATT_ERR_VALUE_NOT_ALLOWED	The attribute parameter value was not allowed.
0x0080	ATT_ERR_APP_ERROR	Application Error
L2C Specific Error		
0x0030	L2CAP_ERR_CONNECTION_LOST	Message cannot be sent because connection lost. (disconnected)
0x0031	L2CAP_ERR_INVALID_MTU_EXCEED	MTU size exceed or invalid MTU proposed
0x0032	L2CAP_ERR_INVALID_MPS_EXCEED	MPS size exceed or invalid MPS proposed
0x0033	L2CAP_ERR_INVALID_CID	Invalid Channel ID
0x0034	L2CAP_ERR_INVALID_PDU	Invalid PDU
0x0035	L2CAP_ERR_UNACCEPTABLE_PARAM	Connection refused - unacceptable parameters
0x0036	L2CAP_ERR_INSUFF_AUTHEN	Connection refused - insufficient authentication
0x0037	L2CAP_ERR_INSUFF_AUTHOR	Connection refused - insufficient authorization
0x0038	L2CAP_ERR_INSUFF_ENC_KEY_SIZE	Connection refused - insufficient encryption key size
0x0039	L2CAP_ERR_INSUFF_ENC	Connection Refused - insufficient encryption
0x003A	L2CAP_ERR_SPSM_NOT_SUPP	Connection refused - SPSM not supported
0x003B	L2CAP_ERR_INSUFF_CREDIT	No more credit
0x003C	L2CAP_ERR_NOT_UNDERSTOOD	Command not understood by peer device



0x003D	L2CAP_ERR_CREDIT_ERROR	Credit error, invalid number of credit received
0x003E	L2CAP_ERR_CID_ALREADY_ALLOC	Channel identifier already allocated
0x003F	L2CAP_ERR_UNKNOWN_PDU	Unknown PDU

GAP Error Codes

0x0040	GAP_ERR_INVALID_PARAM	Invalid parameters set
0x0041	GAP_ERR_PROTOCOL_PROBLEM	Problem with protocol exchange, get unexpected response
0x0042	GAP_ERR_NOT_SUPPORTED	Request not supported by software configuration
0x0043	GAP_ERR_COMMAND_DISALLOWED	Request not allowed in current state.
0x0044	GAP_ERR_CANCELED	Requested operation canceled.
0x0045	GAP_ERR_TIMEOUT	Requested operation timeout.
0x0046	GAP_ERR_DISCONNECTED	Link connection lost during operation.
0x0047	GAP_ERR_NOT_FOUND	Search algorithm finished, but no result found
0x0048	GAP_ERR_REJECTED	Request rejected by peer device
0x0049	GAP_ERR_PRIVACY_CFG_PB	Problem with privacy configuration
0x004A	GAP_ERR_ADV_DATA_INVALID	Duplicate or invalid advertising data
0x004B	GAP_ERR_INSUFF_RESOURCES	Insufficient resources
0x004C	GAP_ERR_UNEXPECTED	Unexpected Error
0x004D	GAP_ERR_MISMATCH	Feature mismatch
0x004E	GAP_ERR_INVALID_BUFFER	Buffer cannot be used due to invalid header or tail length
0x004F	GAP_ERR_BUSY	Request cannot be performed because an on-going procedure blocks it

GATT Error Codes

0x0050	GATT_ERR_INVALID_ATT_LEN	Problem with ATTC protocol response
0x0051	GATT_ERR_INVALID_TYPE_IN_SVC_SEARCH	Error in service search
0x0052	GATT_ERR_WRITE	Invalid write data
0x0053	GATT_ERR_SIGNED_WRITE	Signed write error
0x0054	GATT_ERR_ATT_CLIENT_MISSING	No attribute client defined
0x0055	GATT_ERR_ATT_SERVER_MISSING	No attribute server defined
0x0056	GATT_ERR_INVALID_PERM	Permission set in service/attribute are invalid
0x0057	GATT_ERR_ATT_BEARER_CLOSE	The Attribute bearer is closed
0x0058	GATT_ERR_NO_MORE_BEARER	No more Attribute bearer available

SMP Protocol Errors detected on local device

0x0061	SMP_ERROR_LOC_PASSKEY_ENTRY_FAILED	The user input of passkey failed, for example, the user cancelled the operation.
0x0062	SMP_ERROR_LOC_OOB_NOT_AVAILABLE	The OOB Data is not available.
0x0063	SMP_ERROR_LOC_AUTH_REQ	The pairing procedure cannot be performed as authentication requirements cannot be met due to IO capabilities of one or both devices.
0x0064	SMP_ERROR_LOC_CONF_VAL_FAILED	The confirm value does not match the calculated confirm value.
0x0065	SMP_ERROR_LOC_PAIRING_NOT_SUPP	Pairing is not supported by the device.



0x0066	SMP_ERROR_LOC_ENC_KEY_SIZE	The resultant encryption key size is insufficient for the security requirements of this device.
0x0067	SMP_ERROR_LOC_CMD_NOT_SUPPORTED	The SMP command received is not supported on this device.
0x0068	SMP_ERROR_LOC_UNSPECIFIED_REASON	Pairing failed due to an unspecified reason.
0x0069	SMP_ERROR_LOC_REPEATED_ATTEMPTS	Pairing or Authentication procedure is disallowed because too little time has elapsed since last pairing request or security request.
0x006A	SMP_ERROR_LOC_INVALID_PARAM	The command length is invalid or a parameter is outside of the specified range.
0x006B	SMP_ERROR_LOC_DHKEY_CHECK_FAILED	Indicates to the remote device that the DHKey Check value received doesn't match the one calculated by the local device.
0x006C	SMP_ERROR_LOC_NUMERIC_COMPARISON_FAILED	Indicates that the confirm values in the numeric comparison protocol do not match.
0x006D	SMP_ERROR_LOC_BREDR_PAIRING_IN_PROGRESS	Indicates that the pairing over the LE transport failed due to a Pairing Request sent over the BR/EDR transport in process.
0x006E	SMP_ERROR_LOC_CROSS_TRANSPORT_KEY_GENERATION_NOT_ALLOWED	Indicates that the BR/EDR Link Key generated on the BR/EDR transport cannot be used to derive and distribute keys for the LE transport.

SMP Protocol Errors detected by remote device

0x0071	SMP_ERROR_REM_PASSKEY_ENTRY_FAILED	The user input of passkey failed, for example, the user cancelled the operation.
0x0072	SMP_ERROR_REM_OOB_NOT_AVAILABLE	The OOB Data is not available.
0x0073	SMP_ERROR_REM_AUTH_REQ	The pairing procedure cannot be performed as authentication requirements cannot be met due to IO capabilities of one or both devices.
0x0074	SMP_ERROR_REM_CONF_VAL_FAILED	The confirm value does not match the calculated confirm value.
0x0075	SMP_ERROR_REM_PAIRING_NOT_SUPP	Pairing is not supported by the device.
0x0076	SMP_ERROR_REM_ENC_KEY_SIZE	The resultant encryption key size is insufficient for the security requirements of this device.
0x0077	SMP_ERROR_REM_CMD_NOT_SUPPORTED	The SMP command received is not supported on this device.
0x0078	SMP_ERROR_REM_UNSPECIFIED_REASON	Pairing failed due to an unspecified reason.
0x0079	SMP_ERROR_REM_REPEATED_ATTEMPTS	Pairing or Authentication procedure is disallowed because too little time has elapsed since last pairing request or security request.
0x007A	SMP_ERROR_REM_INVALID_PARAM	The command length is invalid or a parameter is outside of the specified range.
0x007B	SMP_ERROR_REM_DHKEY_CHECK_FAILED	Indicates to the remote device that the DHKey Check value received doesn't match the one calculated by the local device.
0x007C	SMP_ERROR_REM_NUMERIC_COMPARISON_FAILED	Indicates that the confirm values in the numeric comparison protocol do not match.
0x007D	SMP_ERROR_REM_BREDR_PAIRING_IN_PROGRESS	Indicates that the pairing over the LE transport failed due to a Pairing Request sent over the BR/EDR transport in process.
0x007E	SMP_ERROR_REM_CROSS_TRANSPORT_KEY_GENERATION_NOT_ALLOWED	Indicates that the BR/EDR Link Key generated on the BR/EDR transport cannot be used to derive and distribute keys for the LE transport.

SMP Errors triggered by local device



0x0020	SMP_ERROR_ADDR_RESOLV_FAIL	The provided resolvable address has not been resolved.
0x0021	SMP_ERROR_SIGN_VERIF_FAIL	The Signature Verification Failed
0x0022	SMP_ERROR_ENC_KEY_MISSING	The encryption procedure failed because the slave device didn't find the LTK needed to start an encryption session.
0x0023	SMP_ERROR_ENC_NOT_SUPPORTED	The encryption procedure failed because the slave device doesn't support the encryption feature.
0x0024	SMP_ERROR_ENC_TIMEOUT	A timeout has occurred during the start encryption session.
Profile error codes		
0x0080	PRF_APP_ERROR	Application Error
0x0081	PRF_ERR_INVALID_PARAM	Invalid parameter in request
0x0082	PRF_ERR_INEXISTENT_HDL	Nonexistent handle for sending a read/write characteristic request
0x0083	PRF_ERR_STOP_DISC_CHAR_MISSING	Discovery stopped due to missing attribute according to specification
0x0084	PRF_ERR_MULTIPLE_SVC	Too many SVC instances found -> protocol violation
0x0085	PRF_ERR_STOP_DISC_WRONG_CHAR_PROP	Discovery stopped due to found attribute with incorrect properties
0x0086	PRF_ERR_MULTIPLE_CHAR	Too many Char. instances found-> protocol violation
0x0087	PRF_ERR_NOT_WRITABLE	Attribute write not allowed
0x0088	PRF_ERR_NOT_READABLE	Attribute read not allowed
0x0089	PRF_ERR_REQ_DISALLOWED	Request not allowed
0x008A	PRF_ERR_NTF_DISABLED	Notification Not Enabled
0x008B	PRF_ERR_IND_DISABLED	Indication Not Enabled
0x008C	PRF_ERR_FEATURE_NOT_SUPPORTED	Feature not supported by profile
0x008D	PRF_ERR_UNEXPECTED_LEN	Read value has an unexpected length
0x008E	PRF_ERR_DISCONNECTED	Disconnection occurs
0x008F	PRF_ERR_PROC_TIMEOUT	Procedure Timeout
0x00FD	PRF_CCCD_IMPR_CONFIGURED	Client characteristic configuration improperly configured
0x00FE	PRF_PROC_IN_PROGRESS	Procedure already in progress
0x00FF	PRF_OUT_OF_RANGE	Out of Range
LL Error codes conveyed to upper layer		
0x0091	LL_ERR_UNKNOWN_HCI_COMMAND	Unknown HCI Command
0x0092	LL_ERR_UNKNOWN_CONNECTION_ID	Unknown Connection Identifier
0x0093	LL_ERR_HARDWARE_FAILURE	Hardware Failure
0x0094	LL_ERR_PAGE_TIMEOUT	BT Page Timeout
0x0095	LL_ERR_AUTH_FAILURE	Authentication failure
0x0096	LL_ERR_PIN_MISSING	Pin code missing
0x0097	LL_ERR_MEMORY_CAPA_EXCEED	Memory capacity exceed
0x0098	LL_ERR_CON_TIMEOUT	Connection Timeout
0x0099	LL_ERR_CON_LIMIT_EXCEED	Connection limit Exceed



0x009A	LL_ERR_SYNC_CON_LIMIT_DEV_EXCEED	Synchronous Connection limit exceed
0x009B	LL_ERR_ACL_CON_EXISTS	ACL Connection exists
0x009C	LL_ERR_COMMAND_DISALLOWED	Command Disallowed
0x009D	LL_ERR_CONN_REJ_LIMITED_RESOURCES	Connection rejected due to limited resources
0x009E	LL_ERR_CONN_REJ_SECURITY_REASONS	Connection rejected due to security reason
0x009F	LL_ERR_CONN_REJ_UNACCEPTABLE_BDADDR	Connection rejected due to unacceptable BD Addr
0x00A0	LL_ERR_CONN_ACCEPT_TIMEOUT_EXCEED	Connection rejected due to Accept connection timeout
0x00A1	LL_ERR_UNSUPPORTED	Not Supported
0x00A2	LL_ERR_INVALID_HCI_PARAM	invalid parameters
0x00A3	LL_ERR_REMOTE_USER_TERM_CON	Remote user terminate connection
0x00A4	LL_ERR_REMOTE_DEV_TERM_LOW_RESOURCES	Remote device terminate connection due to low resources
0x00A5	LL_ERR_REMOTE_DEV_POWER_OFF	Remote device terminate connection due to power off
0x00A6	LL_ERR_CON_TERM_BY_LOCAL_HOST	Connection terminated by local host
0x00A7	LL_ERR_REPEATED_ATTEMPTS	Repeated attempts
0x00A8	LL_ERR_PAIRING_NOT_ALLOWED	Pairing not Allowed
0x00A9	LL_ERR_UNKNOWN_LMP_PDU	Unknown PDU Error
0x00AA	LL_ERR_UNSUPPORTED_REMOTE_FEATURE	Unsupported remote feature
0x00AB	LL_ERR_SCO_OFFSET_REJECTED	Sco Offset rejected
0x00AC	LL_ERR_SCO_INTERVAL_REJECTED	SCO Interval Rejected
0x00AD	LL_ERR_SCO_AIR_MODE_REJECTED	SCO air mode Rejected
0x00AE	LL_ERR_INVALID_LMP_PARAM	Invalid LMP parameters
0x00AF	LL_ERR_UNSPECIFIED_ERROR	Unspecified error
0x00B0	LL_ERR_UNSUPPORTED_LMP_PARAM_VALUE	Unsupported LMP Parameter value
0x00B1	LL_ERR_ROLE_CHANGE_NOT_ALLOWED	Role Change Not allowed
0x00B2	LL_ERR_LMP_RSP_TIMEOUT	LMP Response timeout
0x00B3	LL_ERR_LMP_COLLISION	LMP Collision
0x00B4	LL_ERR_LMP_PDU_NOT_ALLOWED	LMP Pdu not allowed
0x00B5	LL_ERR_ENC_MODE_NOT_ACCEPT	Encryption mode not accepted
0x00B6	LL_ERR_LINK_KEY_CANT_CHANGE	Link Key Cannot be changed
0x00B7	LL_ERR_QOS_NOT_SUPPORTED	Quality of Service not supported
0x00B8	LL_ERR_INSTANT_PASSED	Error, instant passed
0x00B9	LL_ERR_PAIRING_WITH_UNIT_KEY_NOT_SUP	Pairing with unit key not supported
0x00BA	LL_ERR_DIFF_TRANSACTION_COLLISION	Transaction collision
0x00BC	LL_ERR_QOS_UNACCEPTABLE_PARAM	Unacceptable parameters
0x00BD	LL_ERR_QOS_REJECTED	Quality of Service rejected
0x00BE	LL_ERR_CHANNEL_CLASS_NOT_SUP	Channel class not supported
0x00BF	LL_ERR_INSUFFICIENT_SECURITY	Insufficient security
0x00C0	LL_ERR_PARAM_OUT_OF_MAND_RANGE	Parameters out of mandatory range
0x00C2	LL_ERR_ROLE_SWITCH_PEND	Role switch pending



0x00C4	LL_ERR_RESERVED_SLOT_VIOLATION	Reserved slot violation
0x00C5	LL_ERR_ROLE_SWITCH_FAIL	Role Switch fail
0x00C6	LL_ERR_EIR_TOO_LARGE	Error, EIR too large
0x00C7	LL_ERR_SP_NOT_SUPPORTED_HOST	Simple pairing not supported by host
0x00C8	LL_ERR_HOST_BUSY_PAIRING	Host pairing is busy
0x00CA	LL_ERR_CONTROLLER_BUSY	Controller is busy
0x00CB	LL_ERR_UNACCEPTABLE_CONN_INT	Unacceptable connection initialization
0x00CC	LL_ERR_DIRECT_ADV_TO	Direct Advertising Timeout
0x00CD	LL_ERR_TERMINATED_MIC_FAILURE	Connection Terminated due to a MIC failure
0x00CE	LL_ERR_CONN_FAILED_TO_BE_EST	Connection failed to be established
0x00CF	LL_ERR_MAC_CONN_FAILED	MAC Connection Failed
0x00D0	LL_ERR_CCA_REJ_USE_CLOCK_DRAG	Coarse Clock Adjustment Rejected but Will Try to Adjust Using Clock Dragging
0x00D1	LL_ERR_TYPE0_SUBMAP_NOT_DEFINED	Type0 Submap Not Defined
0x00D2	LL_ERR_UNKNOWN_ADVERTISING_ID	Unknown Advertising Identifier
0x00D3	LL_ERR_LIMIT_REACHED	Limit Reached
0x00D4	LL_ERR_OPERATION_CANCELED_BY_HOST	Operation Cancelled by Host
0x00D5	LL_ERR_PKT_TOO_LONG	Packet Too Long

Table 1: Host Stack Error Codes